

uniLIGHT Module BLACK.1 PLUS

The **Black.1+** is the compact entry-level version of the uniLIGHT system 1-Channel controller module — now equipped with the **uniLIGHT PLUS** interface and configurable via the **uniLIGHT DESK**. It is easy to use and delivers quick results for all types of model applications. Its primary use is for operating an ACL or BEACON light or just for switchable spotlights.

Highlights of the PLUS Series

Configuration can be set up for classic operation or custom light patterns

Software compatible with **uniLIGHT DESK**

Dynamics more refined, faster and sharper light effects with 32bits depth

Safety basic short-circuit protection, undervoltage and temperature protection settings available

Master-Slave principle no switch needed in the load circuit, activation occurs via remote control

Special functions smooth transition switching, navigation+strobe sport function and max/min level

Operating modes



Classic In standard classic operation, the output generates a light pattern based on the input signal. This mode is typically used for various functions such as flashing or blinking lights but can also be utilized for spotlights or special functions. The servo path is divided into 16 sections, which can be activated based on the transmitter settings.

The blue status LED remains constantly lit in this mode.

- -100% (<1ms pulse length): Light off
- +100% (>2ms pulse length): Light on
- inbetween lie 14 predefined light patterns

Always ensure that the selected light can handle the intensity, particularly regarding heat dissipation.

Note: Short light patterns, such as a single strobe, have a duty cycle of approximately 3% (1/32), a single pulse 6% (2/32), but a double pulse 12%! Always check heat development for your specific application and settings!



Custom in this mode, servo-path is divided into only three sections, corresponding to a 3-position switch.

- **-100%**: The system is turned off
- **middle position** or below: the first custom pattern is activated
- **up to 100%**: the second custom pattern is activated

The blue status LED remains on with short interruptions to indicate this operating mode.

Those light patterns can be freely programmed using **uniLIGHT DESK**. To do so, connect the MODUL-PLUS programming cable to your Windows PC and install the software from our homepage <https://www.unilight.at/downloads>

In **uniLIGHT DESK** select the **BLACK.1 PLUS** controller and follow the on-screen instructions. Each entry includes helpful tips and additional information when clicked upon.

Connection and programming

The lighting system is typically controlled via 3-position switch. The simplest approach is to start from the center position **-1-** and adjust the servo midpoint (Sub-Trim) until a desired light signal is achieved.

- **Position -0- (-100%):** standard state for „all off“.
- **Position -1- (Mitte):** A normal operating light can be set here, e.g., single strobe
- **Position -2- (+100%):** A particularly intense lighting pattern can be activated here to make model more visible in an emergency case

Note: Values may vary depending on the manufacturer. Adjust the range until the desired signal is displayed live.

An example of use with a **Glider-ACL-Light**:

- **Position -0-:** Light off
- **Position -1-:** Normal operating light, e.g. a double strobe.
- **Position -2-:** Highly intense lighting pattern (e.g. „Pseudo“), in case the model is lost in the sky. In case of emergency, overheating of lights can be tolerated if it helps locating the model.

Strobe duration and speed rate

All **uniLIGHT** controllers allow you to adjust the speed or repetition rate of the light pattern using the button. When the button is continuously pressed, the repetition rate gradually slows down until it reaches the slowest setting, then jumps to the fastest speed and goes through the cycle again. A more convenient way to adjust this setting is via **uniLIGHTDESK**.

At the same time pressing the button also saves the setting for a solo-operation, so be mindful of it, if not intended.

Operating without RC

If the controller is to be operated independently (solo mode) without a remote control signal, the desired light pattern must be selected once. To achieve that: connect a servo tester and choose a light pattern. Briefly press the button to store the selection. Finally, to activate the controller, a power source need to be connected to a controller either via a Y-cable from the receiver (without the signal wire) or directly from the lighting battery.

Alternatively, on the back of the controller, there is a solder bridge at the red/black cable, marked as the "ALWAYS ON JUMPER." If this bridge is soldered, the controller will always run as soon and as long as the lighting battery is connected. In solo mode, the yellow/green RX LED will remain off, indicating that no valid RC signal is detected.

Note: The controller always consumes power in solo mode, even when no light pattern is active (blue LED is on). In Master-Slave operation, this prevents the lighting battery from needing to be disconnected separately to avoid self-discharge.

Resetting the Controller

Start the receiver power supply by pushing the SET-button continuously for approximately 10 seconds. When the light signal switches to a steady lighting, the reset is complete and the factory settings are restored.

Note: Safety functions can be disabled for special operation purposes (e.g., Night flight) → uniLIGHT.DESK

Special functions

The **uniLIGHT BLACK.1PLUS** module also allows for various special functions to be assigned to the channel. The easiest way to configure these is via **uniLIGHTDESK** and a programming cable. However, some basic settings can also be selected using the button.


Hold the SET-button and turn on the receiver power supply.

1. After releasing the button, the channel is activated and starts blinking:
 - 1x = special functions OFF
 - 2x = smooth transition switching activated
 - 3x = base level activated
2. To change the setting press the button for about 1 second (watch out for a blue status LED for confirmation)
3. Disconnect the receiver power supply to exit the programming mode.

Smooth Transition switching simulates the effect of incandescent bulbs. Used to imitate a slow-flashing rotating beacons.

Base level is applicable for Sport purposes, adding 10% baseline brightness to the light. This allows strong strobe lights to function as BOTH position and strobe light. Ideal for sport models and helicopters: one light = two functions.

Note: Special functions are controlled via PWM technology. Use twisted cables when possible and install wiring as far from receiver system as possible. Always perform a thorough range test prior operating.



Technical data

Controller receiver:	3.6-9,6V
Light/Load:	6-14V (depending on light)
Dimensions:	45x16x5mm
Weight (without cable):	6g
Electric load/impulse current:	6A up to 16V, 10A max
Galvanically isolated circuits:	JA
Operation without RC:	JA
Effects with adjustable speed rate:	classic 14+2 / custom 2+1

Safety features

If a short circuit or severe overload occurs at the output, the system will attempt to shut it down immediately. The blue LED blinks **ONCE** to indicate this. After approximately 10 seconds, the system will try to restart. This is only a basic protection feature and may be affected by external factors. Short circuits in the lights and wiring should always be avoided!

If undervoltage is detected, the blue LED blinks **TWICE**. The default voltage threshold is set to approximately 6V, optimized for 2S LiPo batteries. This threshold can be adjusted as needed.

If overheating is detected and this function is enabled in **uniLIGHTDESK**, the blue LED blinks **THREE** times.

Temperature measurement is done via the processor and should be considered a rough estimate rather than an exact reading.

All safety features can be configured in **uniLIGHTDESK**, as they may interfere with certain operations. Special Considerations for Night Flying: In night flying scenarios, a fully depleted battery may be preferable over an automatic shutdown due to undervoltage. Similarly, if a cable or light gets damaged, the system would not just shut down immediately.